



**KEY NOTES**

- 1 PROVIDE 1" SCH 40 PVC VACUUM LINE TO EACH VACUUM STATION INDICATED. COORDINATE LOCATION AND INSTALLATION WITH DENTIST DRAWINGS.
- 2 PROVIDE 1/2" WATER CONNECTION TO UTILITY J-BOX AT DENTIST CHAIR. SEE DENTIST DRAWINGS FOR EXACT LOCATIONS AND VALVE REQUIREMENTS.
- 3 PROVIDE 1-1/2" DRAIN CONNECTION AND VENT TO UTILITY J-BOX AT DENTIST CHAIR. SEE DENTIST DRAWINGS FOR EXACT LOCATIONS.
- 4 PROVIDE MEDICAL GAS LINES PER DENTIST DRAWINGS FOR N<sub>2</sub>O AND O<sub>2</sub>. COORDINATE ALL LOCATIONS WITH DENTIST DRAWINGS.
- 5 PROVIDE 3/4" CONDENSATE DRAIN DN TO TAILPIECE. DRAIN SHALL TERMINATE WITHIN TENANT SPACE SERVED BY THE AC UNIT.
- 6 SEE DENTIST DRAWINGS FOR INSTALLATION OF N<sub>2</sub>O AND O<sub>2</sub> SYSTEMS
- 7 3/4" CONDENSATE DRAIN UP TO RTU.
- 8 STUB UTILITIES FOR FUTURE OPERATOR.
- 9 1/2"H&CW DN
- 10 1-1/2"SAN DN  
1-1/4"V UP

NO.	REVISION	BY	DATE

**HANDLEY ENGINEERING**  
 130 EL CAMINO REAL, TUSTIN, CA 92780  
 SUITE 200 (714) 669-1141



**SOUTHLAND**  
 energy consultants  
 1481 Gleneyre St., Laguna Beach, CA 92651  
 PH: 949/97-3591 FAX: 949/97-3210  
 Email Address: pekland@el.com

NEW PROFESSIONAL OFFICE FOR:  
**JAMES HOCH, D.D.S.**  
 32246 CLINTON KEITH ROAD, WILDOMAR, CA 92595

DATE:	12.06.11
JOB NO:	H11-135
DRAWN:	JH
CHECKED:	JH
SCALE:	AS NOTED
SHEET	

**P2.0**  
 OF SHEETS